


CNC Insert Up & Down Shear Router Bits

Insert straight router cutter complete with two up-and-down shear flutes and center tip. Shear flutes squeeze the material into the middle to give an extra fine finish on both surfaces of laminated and veneered board. Replaceable inserts ensure a constant cutting diameter and finish quality. Center tip for improved boring. For use on routers with CNC control.



ØD	B	Ød	L	RPM	Tool No.
20 (25/32)	30	3/4"	110	18,000	RC-2300
20 (25/32)	50	3/4"	130	18,000	RC-2304

Replacement Parts



Description	T.C. Blade	T.C. Blade	T.C. Blade	Torx® Key
Tool No.	RCK-16	RCK-28	67112	5090
Size	16x7x1.5	28x7x1.5	M3x4	T9